



A modern, chrome-finished kitchen faucet with a single-lever handle and a pull-out spray nozzle. The faucet has a sleek, minimalist design with a high-arc spout and a cylindrical body. The handle is a simple, flat bar on top of the faucet head. The spray nozzle is attached to the side of the spout and can be pulled out to extend further. The faucet is set against a plain white background.



- Farbe: chrom
- Niederdruck für offene Warmwasserbereiter
- integrierte Vorabsperung
- mittelhoher Auslauf
- Einlochmontage
- GROHE Long-Life Oberfläche
- GROHE SilkMove 35 mm Keramikkartusche
- Auslauf mit Strahlregler
- variabel einstellbare Mengenbegrenzung
- schwenkbarer Gussauslauf
- Schwenkbereich 140°
- Schnell-Montage-System
- flexible Anschlusschläuche

31 120 002 EURODISC COSMOPOLITAN EINHAND-SPÜLTISCHBATTERIE, 1/2"



ERSATZTEILE, März 2010 – jetzt

- 1: Hebel (Bestell-Nr. 46738000)
- 2: Kappe (Bestell-Nr. 46492000)
- 3: Schraubring (Bestell-Nr. 46759000)
- 4: Kartusche (Bestell-Nr. 46558000)
- 5: Dichtungsset (Bestell-Nr. 46760000)
- 6: Strahlregler (Bestell-Nr. 46162000)
- 7: Keramik-Kartusche (Bestell-Nr. 46318000)
- 8: Absperrgriff (Bestell-Nr. 46767000)
- 8.1: Schnappeinsatz (Bestell-Nr. 0538600M)
- 9: Gegenverschraubung (Bestell-Nr. 46249000)
- 10: Montageschlüssel (Bestell-Nr. 19017000)*
- 11: Steckschlüssel (Bestell-Nr. 19332000)*

*Sonderzubehör